


Anziehvorschrift für Zylinderkopf		297.870		Das Original
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a		
		Porsche		
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
⑤ ① ④ ⑦ ⑧ ③ ② ⑥ ⑧ ③ ② ⑥ 				
Anziehen/ * 20 Nm Tightening/ 40 Nm Serrage/ ➤ 90° Apriete ➤ 90°				
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
3,0/3,6 V6 / Cyl. 1-3				
Mot. MCU.RA / MCX.ZA				
MCW.DA / MCW.FA				
309/324 KW (420/441 PS)				
Cayenne				
Panamera				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*297.870*	