

Prescripciones de apriete para culatas

Ford USA



FRONT

7	3	1	5	9
8	4	2	6	10

8	4	2	6	10
7	3	1	5	9

BACK

Anziehen/		25 Nm
Tightening/		40 Nm
Serrage/		90°
Apriete		90°

	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

851.080