

Available again!

Wheel bearing kits for Volvo Trucks and Renault Trucks

Includes installation tool and installation instructions



febi no. 35077



Reference no. Volvo Trucks 21036050
to fit B7R , B9R, B12B, B12M, B13R, FE, FL6, FL7, FL10,
FH12, FH16, FH, FM7, FM9, FM10, FM12, FM, NH12

Reference no. Renault Trucks 74 20 792 439
to fit Kerax, Magnum, Premium

febi no. 35078



Reference no. Volvo Trucks 20967831
to fit B7L, B7L DD, B12B, B12M, FH12, FH, FL6,
FM9, FM12, FM, NH12

Reference no. Renault Trucks 74 21 021 391
to fit Kerax, Magnum, Premium

For more febi spare parts and other wheel bearings please visit: www.trucks.febi-parts.com