



PINCH TAB BUTTON




19mm
SIDE PIN








22mm
SIDE PIN



BAYONET



SLIDE BUTTON



IS2420



HOOK

A



PINCH TAB

B

















22mm
PUSH BUTTON

B



19mm
PUSH BUTTON

B



IS2420