


Seat Ibiza 02-06 Original Vehicle Before Assessment



Seat Ibiza 02-06 Under Bonnet Cross Dimensional Measurement




"X" Measures a distance of: 1329mm

"Y" Measures a distance of: 1328mm

Vehicle Within Required Tolerance

Seat Ibiza 02-06 Under Body Cross Dimensional Measurement



X


Y

"X" Measures a distance of: 1067mm

"Y" Measures a distance of: 1066mm

Vehicle Within Required Tolerance

Seat Ibiza 02-06 Original L/H Front Wing Gaps



4.6mm

3.5mm

3.4mm

3.2mm


3.1mm

No Measurable Gap

2.7mm

3.9mm

Seat Ibiza 02-06 TONG YANG LH Front Wing Gaps



3.2mm

3.5mm

4.6mm

3.4mm


3.1mm

2.7mm


3.9mm

No Measurable Gap



TYG Wing L/H



Original Wing L/H



Seat Ibiza 02-06



TYG Wing L/H

Original Wing L/H



TYG Wing L/H



Original Wing L/H

Seat Ibiza 02-06



TYG Wing L/H



Original Wing L/H

TYG Wing L/H



Original Wing L/H



Seat Ibiza 02-06

