


Seat Ibiza 02-06 Original Vehicle Before Assessment



Seat Ibiza 02-06 Under Bonnet Cross Dimensional Measurement




"X" Measures a distance of: 1332mm

"Y" Measures a distance of: 1332mm

Vehicle Within Required Tolerance

Seat Ibiza 02-06 Under Body Cross Dimensional Measurement



X


Y

"X" Measures a distance of: 1066mm

"Y" Measures a distance of: 1065mm

Vehicle Within Required Tolerance

Seat Ibiza 02-06 Original RH Front Wing Gaps



2.3mm

3.1mm

3.7mm

2.2mm


3.1mm

3.2mm

4.0mm

No Measurable Gap

Seat Ibiza 02-06 TONG YANG RH Front Wing Gaps



2.6mm

3.4mm

3.4mm

2.4mm


3.4mm

4.4mm


No Measurable Gap

4.0mm



TYG Wing R/H



Original Wing R/H



Seat Ibiza 02-06




TYG Wing R/H

Original Wing R/H




TYG Wing R/H




Original Wing R/H

Seat Ibiza 02-06



TYG Wing R/H



Original Wing R/H



Seat Ibiza 02-06

