



Instruction Manual

Part Number:
BENPL-1

**MULTIFUNCTIONAL
PEN LIGHT**

*with UV
and Laser*



Specifications

Product Name	Multifunctional Pen Light with UV and Laser
Material	Nylon PA+Aluminum+PMA
Product Size	165x23mm
Unit Weight	78.7g (with carabiner)
Battery Type	3.7V Lithium-Ion 14500 rechargeable battery
Battery Capacity	800mAh
Charging Port	USB-C
Charging Time	about 3 hours
Input Current	5V 0.5A
Overcharge Voltage	4.2V
Overdischarge Voltage	2.8V
Accessories	User Manual + USB-C Cable

USB-C Charging Port

	LED	Brightness	Runtimes
COB Floodlight	5W COB	450 Lumens	2.5 hours
365nm UV Light	UV Light	/	4 hours
Spotlight	3W LED	140 Lumens	2.5 hours
Laser Light	Red Laser	/	More than 20 hours

Product Material



UV Light

Pure Lighting & Strong Penetration

It can detect pet fungus, clothing, baby products, cosmetics, hygiene products, detergents paper money, oil leakage, antique jade, and identify whether it is repaired, etc.




365nm



Banknote Appreciation
and Anti-counterfeiting



Amber Beeswax
Identification



Pet Fluorescence
Detection

USB-C Input



USB-C charging port


The green light flashes during charging, and five lights are on when fully charged.



Battery Power

- Each light represents approximately 20% of the power.

Button Instruction



① ON/OFF Button

Press the switch to turn on the flashlight, short press the switch within 3 seconds, the light source switches in turn

- the bottom spotlight is on
- the COB floodlight is on
- the top UV is on

Short press for more than 3 seconds to turn off

② Laser Button

Double click the switch to turn on the laser light.
Short press to close.



Bottom Spotlight



Front COB Floodlight



Top 365nm UV Light



Bottom Laser Light

Magnetic Clip

Can be absorbed on
any metal surface
120° rotation to meet
various lighting needs



Charging Instructions Continued

- Multifunctional UV detection laser pointer lamp is a fully rechargeable USB work light so you don't need to buy any batteries.
- Batteries come 80-90% charged so they can be used right away, however it is recommended that you fully charge the battery when received.
- Try and charge the battery BEFORE it's fully discharged.
- Once fully charged, be sure to disconnect the USB charging cable.
- Keep battery away from extreme temperatures especially heat.
- DO NOT attempt to open battery

WARNING!

Children under 6 years old should not use this product without adult supervision.